

## Preventative Maintenance

A preventative maintenance visit from your Branson factory-trained technician helps ensure the continued level of reliability you have become accustomed to with your Branson equipment.

During the visit your technician will check the following parameters and make any corrections necessary – before small problems turn into big ones that could cause down time.

- All Branson-supplied safety devices are in proper operating condition.
- Pneumatic components are operating properly and are free of moisture and other contamination.
- All switches and relays are properly operating and not worn.
- Any moveable assemblies will be checked for freedom of movement, deflection, and signs of wear.
- Connectors and harness assemblies will be inspected for signs of wear and possible electrical breakdown.
- Your incoming electrical system will be checked, and the power supply input transformer adjusted if necessary.
- The entire system will be thoroughly cleaned. All filters will be inspected and replaced if necessary.
- The ultrasonic stack will be disassembled, inspected, lapped if necessary, and properly reassembled. The power supply will then be properly tuned.
- All controls will be tested for proper operation.
- A complete record with any recommendations will be completed before the technician leaves.

To discuss your Services/Solutions options with Branson, please contact your local Branson representative or our headquarters.